Baikal Half-height Truck Canopy Installation Guide

Overall Display




Special Note: Threadlocker has been used for this installation, and the entire assembly must be completed within four hours.

Baikal Half-height Truck Canopy Installation Accessories Material Sheet

Accessory Kit Code	Product Code	Product Picture	Product Name	Product Quantity
A	1		Door gap sealing rubber strip	1
B	1		304 Stainless steel sleeve	32
	2		Round head square neck bolt M8*25	16
C	1		Cap nut M8	12
	2		Washer	12
D	1		Waterproof rubber strip for truck canopy sealing plate	1
E	1		Torx pin anti-theft round head screw M4*20	8
F	1		Cap nut M6	4
	2		Hexagonal flange nut with anti-slip teeth M6	8
G	1		European standard 30MM slide nut	8
	2		Spring washer	8
	3		Hexagon socket head cap screw M6*20	8
H	1		Through bolt	4
I	1		Handle	3
	2		Hexagon socket round head screw M6*10	6
J	1		Hexagon socket low head screw M6*25	4
K	1		Truck canopy bottom rubber strip	1

Baikal Half-height Truck Canopy Installation Steps

Step 1
Insert the front and rear doors into the corresponding positions on the roof as shown in figure 1. Use a rubber mallet as an auxiliary tool to avoid damaging the profiles during installation.




Step 2
Install the door gap sealing rubber strip to the designated areas of the front and rear doors as shown in Figure 2.

The used accessory kit

Accessory kit A





Baikal Half-height Truck Canopy Installation Steps

Step 3
Place the round head square neck bolts M8*25 into the profile notches of the roof as shown in Figure 3, and secure them to the rails with eight bolts on each side. Fit two 304 stainless steel sleeves onto each bolt, and arrange all the bolts evenly.


The used accessory kit

Accessory kit B





Step 4
Place the inner plate on the top as shown in Figure 4. Position the side with reinforcing columns facing downward, align the bolts with the corresponding holes, and finally ensure the cover plate is centered.




Baikal Half-height Truck Canopy Installation Steps

Step 5
Fit the cap nuts M8 together with washers onto the bolts of the top cover assembly as shown in Figure 5. Note that the nuts are not to be installed on the left and right sides; only pre-install the six in the middle and do not fully tighten them for the time being.

The used accessory kit

Accessory kit C






Step 6
Clip the waterproof rubber strips for truck canopy sealing plate onto the raised parts of the left, right, and front edges as shown in Figure 6. (Note the correct orientation.) The application starting point and pattern shall be aligned with the relevant parts.

The used accessory kit


Accessory kit D





Baikal Half-height Truck Canopy Installation Steps

Step 7
Apply soapy water in advance to the rubber strips and the connecting notches on the roof, as shown in the arrow in Figure 7 to facilitate installation. Then mount the side door plates on both sides simultaneously.



Step 8
Fasten the side door plates in sequence with the used accessory kit as shown in Figure 8. Apply threadlocker to pre-install the screws and fully tighten the screws for the time being!

The used accessory kit

Accessory kit E






Baikal Half-height Truck Canopy Installation Steps

Step 9
Insert the European standard 30MM sliding nut into the slot of the side door plate as shown in Figure 9.2. Then place the hexagonal neck profile on the top of the truck canopy, adjust it to the appropriate position, and secure it with the holes (use the hexagonal socket head cap screws M6*20 with spring washers to fix the hexagonal neck profile to the top of the truck canopy. Apply threadlocker when pre-installing the screws, and retighten after confirming the position.

The used accessory kit

Accessory kit G






Baikal Half-height Truck Canopy Installation Steps

Step 10
Connect the joints between the side door plates and the front and rear doors with hexagon socket head cap screws M6*20 as shown in Figure 10.1. Then secure the hexagonal flange nuts with anti-slip teeth M6 to connect the screws on both sides.
Step 10.2 Fit the end caps on the ends of the cover plate.Retighten all the screws of the side and f ro top plate.
Observe the screws installed in Step 8.1

The used accessory kit

Accessory kit F





Step 11
Install the handles on the side doors and front doors with hexagon socket round head screws M6*20 as shown in Figure 11.

The used accessory kit

Accessory kit I






Baikal Half-height Truck Canopy Installation Steps

Step 12
Install the canopy over as shown in Figure 12.1. Secure the front and rear doors to the bottom stringer profiles with hexagon socket low head screws M6*25 and fully tighten the cap nut screws (only installed on the front and rear doors).
Use threadlocker for assembly screws, and tighten them after confirming the positions.

The used accessory kit

Accessory kit J





Step 13
Attach the truck canopy bottom rubber strips to the notches of the bottom profiles. Make sure to cut off the excess glue to fit the two ends of the strip in place.
Make the rubber strip 10 mm closely to the bottom of the profile.
All profiles have been installed. Please refer to the loading instruction guide.

The used accessory kit

Accessory kit K





Baikal Half-height Truck Canopy Installation Kit

Check if all components are complete after unpacking.

